

Installation Instructions

Hose Master's Primary Flex Connector Pipe for Underground, Sump and/or Aboveground Petroleum Systems. Suitable for use with Petroleum Products, Alcohols and Alcohol-Gasoline Mixtures.

IMPORTANT INFORMATION: FOLLOW ALL INSTRUCTIONS CAREFULLY

INSTALLATION SHOULD BE MADE IN ACCORDANCE WITH THESE INSTRUCTIONS AND ALSO WITH STANDARD PIPING PRACTICES RECOMMENDED BY API AND PEI. IF YOU HAVE ANY QUESTIONS ABOUT THESE INSTRUCTIONS OR ABOUT THE API OR PEI RECOMMENDED PIPING PRACTICES, STOP AND CONTACT HOSE MASTER BEFORE PROCEEDING. ONLY FOR ASSEMBLY AND INSTALLATION BY QUALIFIED PERSONS. THE USE OF NON-QUALIFIED PERSONNEL, OR ANY DEVIATIONS FROM THESE RECOMMENDED PROCEDURES, COULD RESULT IN DAMAGE OR LEAKAGE.

Instructions also available at www.hosemaster.com/pei

INSTALLER: AFTER INSTALLATION, GIVE THESE INSTRUCTIONS TO THE OWNER OR OPERATOR OF THE FACILITY WHERE THE INSTALLATION IS DONE.

PROPER STORAGE:

The connector is not intended for storage in excessive temperatures or humidity, where it can be exposed to corrosives, or subject to rough handling (drops, impacts, crushing, dragging, etc.). Any of these during storage or transit may cause damage and leaks during use.

INSPECT THE CONNECTOR BEFORE INSTALLATION:

The connector should not have any signs of damage (impact damage, loose braid, discoloration, damage to threads, etc.). If there are any signs of damage, do not use connector.

DO NOT TWIST OR COMPRESS CONNECTOR:

Twisting or compressing the connector during installation or service must be avoided. Torque or compression will lead to the premature failure of an assembly.

DO NOT PUT WRENCHES ON HOSE OR BRAID COLLAR:

Wrenches must only be used on the hex of the fitting. Do not tighten fittings more than 3 turns past hand tight.

DO NOT OVERBEND THE CONNECTOR: